




Advance User Manual

Vacuum (B) & Non-Vacuum (N) Autoclaves



Integrated decontamination solutions



Instructions for use

Please read these instructions before using the autoclave.

Keep these “Instructions for use” in a safe place close by the unit for future reference.

Service Helpline: Telephone: 01254 844 116

(UK only - 24hr)

e.mail: customerservice@prestigemical.co.uk

Prestige Medical Service staff are available to provide advice and assistance during normal office hours. To avoid delays when making contact please have the units Model and Serial Numbers at hand. These can be found on the rating plate located at the rear of the unit or on the bezel inside the door.

For additional information visit

www.prestigemical.co.uk

UK Customers

Prestige Medical Limited
East House, Duttons Way,
Shadsworth Business Park,
Blackburn BB1 2QR

Tel : +44 (0) 1254 682 622
Fax : +44 (0) 1254 682 606

www.prestigemical.co.uk
sales@prestigemical.co.uk

Overseas Customers

Contact your local distributor. In case of doubt contact Prestige Medical.

Contents.

Section	Page
1 Introduction	3
2 Operating Symbols, Displays and Controls	4
3 Operation	6
4 Essential Information	9
5 Routine Care and Maintenance	10
6 Trouble Shooting	11
7 Recovery Sequences	12
8 Additional Information	13
9 Warranty	14
10 Printer and data logger Instructions	14
11 Specification	15
12 Cycle Profiles	16
13 Water Quality	19
14 Loading the Autoclave	19
15 Daily Record Sheet	20

Destination Kit

Date of purchase

Model no.

Vessel rating plate (duplicate)

Serial no.



BSI EN ISO 9001:2000 Cert No FM31988 | ISO 13485:2003 Cert No FM29156

Prestige Medical Limited
East House, Duttons Way,
Shadsworth Business Park,
Blackburn BB1 2QR
Tel : +44 (0) 1254 682 622
Fax : +44 (0) 1254 682 606
www.prestigemical.co.uk
sales@prestigemical.co.uk
Registered in England
Reg No. 2826793

Section 1: Introduction

Thank you for choosing the Prestige Medical Advance Autoclave. This machine is fitted with sophisticated control software and will automatically adjust the cycle time dependent on the mass of load used. This will ensure the optimum sterilizing and drying conditions for all loads.

All “Type B” vacuum cycles use the triple pulse fractionated vacuum system. Non-vacuum cycles use the thermodynamic air displacement system. Vacuum Drying cycles employ a “closed door” system. Non-vacuum machines employ an “open door” system.

An “Auto-cycle start” option is included which allows the user to programme the time of day at which the selected cycle should start.

Before unpacking, refer to the “Manual Handling” section on page 13, section 8.

Whilst unpacking check the unit for transit damage. If damage is found, please report this to the shipping agent immediately, in writing, and then notify your dealer.

Product contents comprise of the following: -

- Autoclave with internal furniture.
- Instructions for use.
- Performance Test Certificate and Certificate of Conformance for pressure vessel (all UK models).
- Installation sheet.
- Written Scheme of Examination (UK models).
- Waste water container.
- Printer or Data Logger (if applicable).

Types of load and loading.

Advance autoclaves are designed to sterilize instruments, utensils and other items as defined by the European Standard EN13060.

Only the vacuum models can effectively sterilize wrapped or pouched instruments and hollow loads.

The autoclaves operate automatically with 134°C and 121°C sterilizing temperatures (with or without drying).

For a full list of sterilizing cycles and times refer to Section 12.

WARNING!

Refer to the instrument manufacturer to ensure the instruments suitability for autoclaving and the maximum temperature they can withstand.

A “responsible person” must qualify other loads as suitable. Refer to “Additional Information” in Section 8. Refer to “Technical Specifications”, Section 11, for the maximum instrument load for the autoclave.

All instruments must be cleaned appropriately prior to sterilizing.

Wrapped or pouched loads should not touch adjacent loads. Pouches must be used for one item only.

When placing items on a pouch tray, ensure they do not touch each other and that the load does not touch other trays or the chamber..

Always use the lifting device when removing pouch trays from the autoclave as they may be hot.

Long trays should be supported at their rear as they become free of the tray carrier.

Pouched instruments should be placed on pouch trays for best drying results

Do not use an unprotected hand to hold hot trays.

Section 2: Operating symbols, displays and controls

The following descriptions refer to the symbols, controls and displays used on the **ADVANCE** range of autoclaves.



IMPORTANT: Read Operating Instructions before use.



Hot parts. Do Not Touch.



Fill water tank when LED illuminated (Maximum fill level is S3 opposite).



Do not use tap water (S2 below). For acceptable water quality refer to Section 13.



Symbols:

- S1 Cycle status.
- S2 Do not use tap water.
- S3 Maximum water fill line.
- S4 Fill water tank

General controls / Operations:





Note: The function is selected when the LED adjacent to the button is illuminated.

- A Standby / Ready button.
- B Cycle start button.
- C Door open button.
- D Adjust time/date settings
- E1 Adjust date/time settings (hidden)
- E2 Accept (hidden)
- F Select vacuum cycles.
- G Select non-vacuum cycles.
- H Select additional drying.
- I On/off switch
- J Printer socket
- K Main door.
- L Fresh water drain.
- M Water fill.
- N Air filter.
- O Rating plate.
- P Power Inlet.





Cycle controls vacuum models.





Press F to select the **vacuum** cycles these are as follows:

-  134°C /3½ min. Vacuum cycle for porous loads, wrapped, pouched, solid / hollow instruments with drying.
-  134°C /18 min. Vacuum cycle for porous loads, wrapped, pouched, solid / hollow instruments with drying.
-  134°C /3½min. Cycle for bagged solid instruments **without** drying. Additional drying should be added.
-  134°C /3½min Vacuum cycle for unwrapped solid or hollow instruments/ Steam penetration test **without** drying. Suitable for Bowie Dick Test Pack or Helix.


Press G to select **non-vacuum** cycles.

-  121°C 121°C /15½min. Non-vacuum cycle for unwrapped solid instruments, **without** drying.
-  134°C 134°C /3½min. Non-vacuum cycle for unwrapped solid instruments, **without** drying.

Cycle controls non-vacuum models.

-  121°C
-  134°C
-  Non-vacuum cycle for unwrapped solid instruments, **without** drying.
-  Non-vacuum cycle for unwrapped solid instruments, **with** drying.

The 121°C or 134°C led will be illuminated to show which cycle is selected.




Examples below show:-


Press H to select 'Additional drying' in 5 minute increments up to a maximum of 15 minutes.



AFTER EVERY CYCLE THE UNIT RETURNS TO THE DEFAULT CYCLE.




Display Options. (Figures shown are for a vacuum unit)



- L1 Display for "Time" "Date" & "Cycle counter". (Vacuum units only) The normal display mode is time. The date or cycle counter can be selected by pressing the button D adjacent to the display. The selection is valid until a cycle is completed or until the unit is returned to standby mode, at which point the display will revert to the current time.
- L2 Display for "Temperature"
- L3 Display for "Pressure".

The following show the cycle status: (Vacuum unit)



- L4 Cycle started.
- L5 Heating and air bleed.
- L6 Sterilizing.
- L7 Depressurisation / drying.
- L8 Cycle complete.

Section 3: Operation




Please take time to read these instructions before using the autoclave. It is essential that the operator is correctly trained and a “Responsible Person” has been assigned for the management of the autoclave. By following these simple step-by-step instructions you can ensure your instruments are correctly sterilized every time.

1. Installation.

Ensure the unit is placed on a strong, flat, level & heat resistant surface



Adjust the feet so that the unit is level when viewed from the front, but angled backwards when viewed from the side (see illustration). To



check that the unit is set up correctly, pour half a cup of water into the chamber. The water should flow towards the hole at the rear of the chamber not out of the front. If this happens, re-adjust the feet.

WARNING!

The autoclave is heavy; at least two people will be needed to lift it.

2. Connection.

Plug the unit into the mains outlet socket of the correct type & rating. See rating plate (O). Push the on/off switch on the front of the unit.

After a few seconds the LED next to button (A) illuminates and the internal heater operates to control the internal temperature at a set value.

WARNING!

The mains outlet **MUST BE EARTHED (GROUNDED)**. The mains plug should always be easily accessible as it is to be relied upon as “the means of disconnection”.

3. Single use water system.



This unit has a “single use” water system designed to prevent the recycling of any contaminants, which may be present on the instruments being sterilized.

Ensure the waste water container is emptied to the minimum level prior to filling the fresh water tank to the maximum level.

Ensure the “waste water container” is checked regularly to prevent overflowing. The container should be emptied when the waste water level reaches the “Max” line.

To empty the container, undo the screw cap and carefully remove the steam condensing coil/cap assembly.

Use the carry handle to support the container when emptying. Replace the steam-condensing coil and cap; ensuring it is screwed on securely.

Note: Before using for the first time, and after emptying, always add cold (tap) water until the level reaches the minimum level mark.

The waste water container can be located in any convenient place, although care should be taken that it cannot be knocked over.

WARNING!

Waste water and steam condensing coil may be hot. Care should be taken at all times.

4. Setting date and time.

Date and time are set in the following sequence.

Note: This unit uses a 24 hour clock.

Year (tens): Year (hundreds): Month: Day: Minutes: Hours.

- Set the autoclave in “Ready Mode” by pressing ready button (A). The LED next to button (A) will then go out.
- Press and hold button (D) for 5 seconds.
- Set year (tens) by pressing button (D) up and (E1) down. Press button (E2) to accept.
- Set year (hundreds); Month; Day; Minutes; hours; by pressing button (D) up and (E1) down. Press button (E2) to accept for each.
- The unit returns to “Ready Mode” when the hours are accepted.

5. Ready.

Press button (A) to set the autoclave into “Ready Mode”. The LED next to button (A) will go out.

Note: When in “Ready Mode”, the boiler and chamber are pre-heated.

6. Water fill – DO NOT USE TAP WATER.



Before using the autoclave for the first time fill with water.

Always use de-ionised, distilled or sterile water as recommended (see page 19).

NEVER USE TAP WATER. THIS WILL INVALIDATE THE WARRANTY.

Press button (C) to open the door. Pour water into the fill spout (M) until it reaches the “Maximum line” (S3). Do not overfill. The water capacity is 3.7 litres. When the low water indicator illuminates, top up with water.


7. Loading.

Refer to “Loading the Autoclave” at Section 14, page 19 and “Specifications” on page 15 for the maximum permissible load.

Failure to follow instructions may cause the unit to malfunction and result in an unsuccessful cycle. Before loading, ensure instruments are cleaned and rinsed thoroughly.

Always use the instrument trays or racks, which are supplied or are available as recommended accessories through your supplier

Load instruments so that they do not touch each other and that the load does not touch other trays or the chamber.



Only one item should be placed in a pouch.

Linen loads should be formed into a rectangular pack of size 110mm x 110mm x 50mm. (maximum), weighing no more than 1 kg. Place on a pouch tray in the middle of the chamber.

Linen loads should not be sterilized in combination with other loads.

8. Door closing.

Once the trays are in place, close the door by pushing until a “click” is heard. The LED next to the door open button (C) will then flash for a period of 20 seconds during which time entry in to the unit is restricted. This ‘dwell’ period is used to ensure correct pressure sensing readings are made prior to a cycle being initiated. Access to the unit can be made once this period is complete.

9. Cycle options.

After each cycle the unit will return to the default cycle.

On Vacuum units this is the 134°C /3½min Vacuum cycle for porous loads, wrapped, pouched, solid / hollow instruments with drying (B cycle).



Cycle options available on the vacuum autoclave are:

Press F to select the **vacuum** cycles these are: -



134°C /3½min. Vacuum cycle for porous loads, wrapped, pouched, solid / hollow instruments with drying.



134°C /18min. Vacuum cycle for porous loads, wrapped, pouched, solid / hollow instruments with drying.




134°C /3½min. Cycle for bagged solid instruments, **without** drying. Additional drying should be added.



134°C /3½min. Steam penetration test **without drying**. Suitable for Bowie Dick Test Pack or Helix.

Press G to select **non-vacuum** cycles.



121°C

121°C /15½min. Non-vacuum cycle for unwrapped solid instruments, **without drying**.



134°C

134°C /3½min. Non-vacuum cycle for unwrapped solid instruments, **without drying**.

On non-vacuum units pressing G allows you to scroll round all the 121°C. and 134°C. cycles.



Non-vacuum cycle for unwrapped solid instruments, **with** drying. Either 121°C /15½min. or 134°C/3½min.



Non-vacuum cycle for unwrapped solid instruments, **without** drying. Either 121°C /15½min. or 134°C/3½min.

Press H to select “**Additional Drying**”.



Additional drying.

This option can be added before or after a cycle.

NB. Additional drying is inactive for the Steam Penetration Test cycle (TP). Drying on this cycle can only be obtained after the cycle has ended by selecting additional drying as described below in (ii).

(i) To select before starting a cycle:

- (i) Press button (H) once. L4 illuminates to indicate 5 additional minutes.
- (ii) Press (H) a second time. L4 & L5 illuminate to indicate 10 additional minutes.
- (iii) Press (H) a third time. L4 L5 & L6 illuminate to indicate 15 additional minutes.
- (iv) Press (H) a fourth time. This cancels additional drying.
- (v) Select, then start the required cycle. See “10”.

(ii) To select after a cycle has been completed:

- (i) With the door closed press and hold button (H) for 10seconds. L7 flashes to indicate 5 minute drying in progress.
- (ii) Press button (H) once. L4 illuminates to indicate 5 additional minutes. Now press and hold button (H) for 10seconds. L4 and L5 are illuminated. Then L7 flashes to indicate 10minute drying in progress.
- (iii) Press button (H) twice. L4 & L5 illuminated to indicate 10 additional minutes. Now press and hold button (H) for 10seconds. L4 L5 and L6 are illuminated. L7 now flashes to indicate 15minute drying in progress.

10. Start cycle.

Press button (B) to start a fully automatic cycle. A visual display shows the stages of the cycle:

Stage 1	Cycle started (L4)
Stage 2	Heating and air bleed (L5)
Stage 3	Sterilizing (L6)
Stage 4	Depressurisation / drying (L7)
Stage 5	Cycle completed (L8)

11. Opening door.

At the end of a cycle a buzzer sounds 3 times. Press button (C) to open the door, allowing access to the load.

Additional operations.

Steam Penetration Test.

On vacuum units the “Steam penetration test” should be performed on a daily basis to confirm that the unit is operating correctly.

A Prestige Medical Bowie Dick Test Pack or an Albert Browne Helix Test MUST be used with this test. The Pack or Helix should be placed on an instrument tray in the middle of the chamber towards the front.



Albert Brown Helix Test



Bowie Dick Test Pack

Run the cycle  for the steam penetration test.

Following this test, the Test Pack or Helix TST should change to a uniform purple colour. If this is not the case, clean the gasket and the chamber rim before repeating the test. If the unit continues to fail, replace the gasket and re-test before contacting the Prestige Medical customer care team or dealer.

If the test fails again seek technical assistance.

Vacuum system leak test.

The “vacuum system leak test” checks the integrity of the vacuum system. **NB. A printer or data logger MUST be fitted.**

The test MUST be undertaken when the unit is cold and dry (before any other cycle has been run).

Set the autoclave in “Standby Mode” by pressing ready button (A). The LED next to button (A) will illuminate.

Press and hold button (F) for 6 seconds. The display (L1) will begin to count down. Hold button (F) until the count down reaches zero. The test will then start.

304278D

During the test, the segments of the cycle status graphic (S1) will flash.

The test will take between 15 to 30 minutes. On completion the print-out will advise if the unit has passed or failed the test.

If a failure occurs, clean the gasket and the chamber rim before repeating the test. If the unit continues to fail, replace the gasket and re-test before contacting the Prestige Medical customer care team or dealer.

To return to normal use press button A, then button C.

Auto-cycle start.

The unit can be programmed to enable any cycle to be started at any time of the day when the unit is unattended. This option is recommended particularly when the operator performs “Air leak detection test”.

- Set the autoclave in “Standby Mode” by pressing ready button (A). The LED next to button (A) will illuminate.
- Press and hold button (D) for 6 seconds and release. The time display (L1) will flash with the default time of 06.30 being displayed.
- Press (E2) to accept. If another time is required for the auto-cycle start, change minutes then hours; by pressing button (D) up and (E1) down. Accept by pressing button (E2).
- The unit returns to “Ready Mode” and the LED to the left of the clock symbol continues to flash.
- Select the required sterilizing cycle using buttons (F), (G) and (H).
- Load the instruments in the chamber and close the door.
- Press the start button (B). The door LED (C) and the start LED (B) both flash. The clock symbol LED is still flashing.
- The selected cycle will start when the programmed start time is reached. The clock symbol LED flashes until the cycle is completed.
- To abort a timed cycle (before the cycle starts) press the “Standby button” (A).

Section 4: Essential information

To ensure that the autoclave continues to operate correctly, it is important to adhere to the following points and to carry out the necessary care and maintenance procedures as specified.

This product is not a washing / cleaning machine.

Do ensure that.....

- ... you read and follow these Instructions for Use.
- ... the load is suitable for sterilizing and the cycle selected.
- ... the load can be sterilized at the selected temperature.
- ... the load has been cleaned.
- ... the load has been rinsed thoroughly in clean water prior to sterilization to avoid any chemical residues left after cleaning contaminating the autoclave.
- ... when placing instruments on trays, ensure they do not touch each other and that the load does not touch other trays or the chamber.
- ... only distilled, de-ionised or sterile water is used (as recommended on page 19).
- ... the autoclave is in a draught free area.
- ... the autoclave is not installed in an enclosed cupboard space.
- ... the door is left ajar when not in use.
- ... you quote model/serial number (which are located on the lower left hand side of the front bezel, behind the door moulding and also on the rear case just above the mains power cord entry) and date of purchase in all correspondence.
- ... only qualified personnel regularly service the autoclave.
- ... all routine care and maintenance procedures are followed

It is recommended that a Chemical Indicator strip be used every cycle to verify that the sterilizing cycle is effective. If the Chemical Indicator strip fails to change colour repeat the cycle. If it still fails to change colour then arrange for a service.

Do not....

- ... lose this handbook.
- ... add any chemicals whatsoever to the water.
- ... attempt to sterilize volatile substances, toxic materials or other unsuitable loads. (Refer to your "Responsible Person" for advice)
- ... place the autoclave in direct sunlight.
- ... place the autoclave on heat sensitive surfaces.
- ... use inappropriate cleaning materials.
- ... drop or abuse the autoclave.
- ... use in areas of risk associated with flammable materials or gases.
- ... remove the casing in an attempt to service or repair the autoclave.


Disposal

WEEE Statement

(Waste, Electrical and Electronic Equipment)

The WEEE directive places an obligation on all EU-based manufacturers and importers to take-back electronic products at the end of their useful life.

Prestige Medical Limited accepts its responsibility to finance the cost of treatment of redundant WEEE in accordance with the specific recycling requirements.



The symbol (shown below) is present on all Prestige Medical products, which indicates that the product must NOT be disposed of with other waste. Instead it is the user's responsibility to dispose of their waste electrical and electronic equipment by handing it over to an approved reprocessor, or by returning it to Prestige Medical for reprocessing. For more information about where you can send your waste equipment for recycling, please contact your local city office or Prestige Medical.

Section 5: Routine care and maintenance

WARNING!

Disconnect the autoclave from the mains power supply before cleaning.

DAILY MAINTENANCE

Gasket

THE GASKET MUST BE CLEANED ON A DAILY BASIS, BEFORE USING THE AUTOCLAVE.



Wipe exposed surface of the gasket with warm soapy water using a lint-free damp cloth.

Gently clean the vessel rim sealing surface with a wet light nylon pan scourer.

Wipe both the gasket and the vessel again with water using a lint-free damp cloth to remove any residual soap.

MONTHLY MAINTENANCE

Cleaning of the fresh water tank

Fully drain the fresh water tank. Pull the drain button underneath the door of the autoclave, remove the pipe from the button and completely drain the water. Refit the button and refill the water tank with 2 caps of the autoclave cleaning solution (part no. 279493) and 1 litre of distilled water. Select and run a sterilization cycle (the quickest one, for example). At the end of the cycle, drain the same way, refit the button and fill with fresh water again. Re-start another quick cycle to remove any residue of cleaning solution. Drain again. Clean the chamber with a lint-free cloth to remove water. Refill with fresh distilled water to use the autoclave.

WARNING

Failure to perform these procedures may result in the unit showing UOD1 on the display (UOD1 indicates that the unit may have been contaminated and could fail to operate correctly).

Exterior surfaces (as required).

Exterior surfaces should be cleaned with warm soapy water using a damp cloth.

For persistent marks, use a gentle cream cleaner.

Always use de-ionised, distilled or sterile water as recommended. NEVER USE TAP WATER.

Gasket replacement

Should the gasket develop a persistent leak it should be removed, cleaned thoroughly in warm soapy water and shaken dry. Wiping with a lint-free cloth is acceptable (Other materials may lead to contamination of the gasket with fibres).

If the leak persists you should obtain and fit a new gasket.


To remove the gasket, undo the two thumb-nuts (309070) in the centre of the gasket plate.



Remove the plate/gasket assembly and then remove the gasket from the plate.

CAUTION: Ensure the gasket is located the right way around on the plate, the lip should face outwards.

During re-assembly, place new black sealing washers (supplied with the gasket) in the machined recesses in the door casting.




Re-fit the gasket/plate assembly. Ensure that the entry port plug aligns with the hole on the right hand side of the door. Replace the 2 white silicone washers. Prior to tightening the 2 thumb nuts, ensure that the gasket is correctly seated on the gasket plate and in the door recess.

DO NOT overtighten the thumb nuts as this may damage the thread.

This autoclave should be serviced and calibrated annually in accordance with Prestige Medical procedures by Prestige Medical or authorised service engineer.

Section 6: Trouble shooting

If the machine does not complete a sterilizing cycle, a visual and audible indication will be given. The reason can then be determined by reference to the guide below. The recovery sequence allows access to any instruments within the autoclave and is the first step when rectifying the condition. **In the unlikely event that a cycle fails to complete, instruments should be reprocessed as they may not be sterile.**

User Message	Cause	Remedy.
UOD1 and UOD2	Unit contamination or gasket wear.	<ul style="list-style-type: none"> • Conduct routine maintenance procedures & re-run cycle • Replace gasket if fault persists • If the condition persists, an engineer may be required
Low water LED Illuminated (S4) 	Insufficient water to run a cycle.	<ul style="list-style-type: none"> • Press button A twice. Top up with water to mark S3
"Door" illuminates on display (L2)	Cycle start button pressed whilst door is open or door microswitch requires adjustment.	<ul style="list-style-type: none"> • If door closed but door LED (C) not illuminated - push on door to see if LED can be illuminated. • If door open, close door and try again. • If fault occurs during a cycle – following recovery sequence "i"
01	Power failure during a cycle.	<ul style="list-style-type: none"> • Recovery sequence "i" • Check power supply – repeat the cycle.
b02	Sterilizing temperature out of range.	<ul style="list-style-type: none"> • Recovery sequence "i" • Conduct routine maintenance procedures & re-run cycle • Replace gasket if fault persists • If the condition persists, an engineer may be required
d02	Probe difference out of range.	<ul style="list-style-type: none"> • Recovery sequence "i" • Conduct routine maintenance procedures & re-run cycle • Replace gasket if fault persists • If the condition persists, an engineer may be required
t02	Clock error.	<ul style="list-style-type: none"> • Recovery sequence "i" • Check and reset the clock - repeat the cycle. • If the condition persists, an engineer is required
p02	Sterilizing pressure out of range.	<ul style="list-style-type: none"> • Recovery sequence "i" • Conduct routine maintenance procedures & re-run cycle • Replace gasket if fault persists • If the condition persists, an engineer may be required
03	Air bleed has not been successful.	<ul style="list-style-type: none"> • Recovery sequence "i" • Conduct routine maintenance procedures & re-run cycle • Replace gasket if fault persists • If the condition persists, an engineer may be required
04	Vacuum failure.	<ul style="list-style-type: none"> • Recovery sequence "i" • Conduct routine maintenance procedures & re-run cycle • Replace gasket if fault persists • Check waste water pipe for kinks • If the condition persists, an engineer may be required
07	Sensor fault – boiler thermistor.	<ul style="list-style-type: none"> • Recovery sequence "ii" - repeat cycle • If the condition persists, an engineer is required
08	Sensor fault – pressure transducer.	<ul style="list-style-type: none"> • Recovery Sequence "ii" – Repeat cycle. • If fault persists engineer call-out may be required.
10	Water in the boiler.	<ul style="list-style-type: none"> • Recovery sequence "iii"- repeat cycle running a 134°C non vacuum cycle • Check whether a previous error code was displayed • If fault persists, an engineer is required
00D3	Vacuum failure in drying stage	<ul style="list-style-type: none"> • Recovery sequence "i" • Conduct routine maintenance procedures & re-run cycle • Replace gasket if fault persists • Check waste water pipe for kinks • If the condition persists, an engineer may be required
13	Water fill time out.	<ul style="list-style-type: none"> • Recovery sequence "i" • Drain water out of the fresh water tank and refill with de-ionised, distilled or sterile water. • Repeat the cycle.
14	Sensor fault – Chamber probe.	<ul style="list-style-type: none"> • Recovery sequence "ii" - repeat cycle • If fault persists, an engineer is required
15	System Leak.	<ul style="list-style-type: none"> • Recovery sequence "ii" • Conduct routine maintenance procedures & re-run cycle • Replace gasket if fault persists • If the condition persists, an engineer may be required

Engineer call-outs due to a lack of housekeeping and routine maintenance can be expensive. Please ensure that all consumable items have been cleaned or replaced as appropriate and that the water quality is as described in Section 13 before contacting Prestige Medical. For engineer assistance, please contact our Customer Care Team on **01254 844 116** or email: customerservice@prestigemedical.co.uk

Section 7: Recovery sequence (allows instruments to be removed from the unit).

Recovery Sequence (allows instruments to be removed from the unit).		
Recovery Sequence “i”	Recovery Sequence “ii”	Recovery Sequence “iii”
Press button (A) Stabilize (no flashing or beeping)	Press button (A) Stabilize (no flashing or beeping)	Press button (A) Stabilize (no flashing or beeping)
Service required. Press button (A) “Recover”	NB: Cannot proceed. Switch off at mains supply. Service required.	Press button (A) to enter “Ready Mode”

The Recovery sequence (depending on where the fault occurs) will flush the water from the boiler and eventually complete the cycle with a continuous beeping to indicate recovery is completed.

Important.

Before restarting a cycle, check that the mains plug is fully inserted into the mains outlet socket and the outlet is of the earthed/grounded type.

Should all power be lost the door cannot be opened until power is restored and pressure returned to ambient.

Should an internal power failure occur, the door cannot be opened until: -

1. The unit has cooled down to atmospheric pressure. Access can then be made using the supplied tool.
2. A service has been carried out.

In the event of failure of an indication device a service will be required to correct the condition.

Should a safety feature operate, unplug the unit and call for a service – do not attempt to correct the fault.

Primary safety features:

Two primary features have been fitted – a pressure release valve and a boiler over temperature safety cut out.

IMPORTANT NOTE ON EMERGENCY DOOR OPENING PROCEDURES.

If the door interlock lever does not fully release during door opening and the door led has gone out, light pressure on the door will re-illuminate the door open led. It will then be possible to open the door in the normal manner using the door open button.

Door opening – Power loss.

If the machine has suffered a loss of power and it is essential to open the machine to remove instruments, the following procedure should be followed. This should only be performed by the nominated responsible person: -

1. Disconnect the unit from the mains supply.
2. Allow the machine to cool down to room temperature.
3. Remove the protective white protective cap on the top of the machine.
4. Locate the Vessel Pressure Release button on top of the unit and pull button fully upwards to release the valve and any pressure/vacuum left inside the autoclave.
5. Insert the straight end of the special tool into the interlock lever release guide hole and push inwards. If the tool starts to buckle at the preformed strain relief repeat from 3 above.

See Photograph opposite.

DO NOT ATTEMPT TO OPEN THE VESSEL IF PRESSURISED.

ONLY USE THE TOOL PROVIDED AND FOLLOW THE INSTRUCTIONS ABOVE TO GAIN ACCESS TO THE MACHINE.



Section 8: Additional information

Operator:

The person assigned to use the autoclave.

Responsible person:

The person who is responsible for the management of the equipment, load assignment, care and maintenance. This person is also responsible for ensuring that all applicable Health & Safety Regulations are applied including those relating to the pressure vessel.

This person must verify that only suitably qualified persons undertake repair and maintenance work other than that described under "Routine Care and Maintenance" within this handbook.

Qualified person:

A person who is qualified by training or experience to a recognised level in respect of the work to be undertaken.

Service:

Calibration and maintenance as required.

Manual handling:

Due to the weight of the unit two people are required when unpacking or moving the product.

UNPACKING.

When lifting the unit out of the box ensure there is one person on either side of the unit. Lift out of the box and place on the work surface.

POSITIONING.

Start lifting by holding the unit below the front bezel (large plastic moulding). As clearance is gained, lift at the other corners. Place in position, and release in the reverse order to lifting. **NOTE** Always drain the water tank before moving. Before moving always allow 30 minutes after use for the unit to cool down.

Cleaning materials:

Mild washing up liquid. Non-abrasive cream cleaner. Disinfectant diluted in water. Autoclave Cleaning Kit 279493.

Product decontamination.

Should the unit require to be returned to the factory for repair, it must be decontaminated in accordance with our recognised procedures.

Approvals:

Approvals are all model specific. However, the following standards apply in whole or part:

- Medical Devices Directive MDD 93/42/EEC
- Pressure Equipment Directive PED 97/23/EC
- RoHS2 Directive 2011/65/EU
- Small Steam Sterilizer Standard EN 13060
- Electrical Safety Standard EN 61010
- EMC Standard EN 61326

Spares:

Only those spare parts supplied or specified by Prestige Medical should be used in the maintenance of the autoclave. Use of unauthorised parts will invalidate any warranty and may adversely affect the performance or safety of the unit.

Accessories / Consumables

Printer (Part No.)	279519 Europe
	279520 UK
	279521 Australia

Data Logger	279565
--------------------	---------------

Optional and can be fitted by the user.

Printer roll (Part No.279505): Ten replacement rolls.

Furniture:

22 litre pouch tray (Part No. 309071)

16 litre pouch tray (Part No.309066)

Tray lifter (Part No.279007)

Door tool (Part No.309068)

Door plate thumb screw (Part No.279300)

Set of 4 gaskets (Part number 279571)

"O" Ring door (Part No.279100)

Waste Water Container (Part No.279503)

Container for single use water.

Bowie Dick Test Pack (Part No.309031)

Helix Test Pack (Part No. 329001)

TST strips (Part No. 259277)

Autoclave cleaner (Part No 279493)

For cleaning the autoclave to ensure continued operation.

Air filter (Part No. 273096A screw-in type; Part No. 309077 push-in type).

3 Tray Rack (Part No.289132)

Set of twelve 10 instrument clip trays (Part No. 309082)

Set of two 3 instrument clip trays (Part No.276396A)

Section 9: Warranty (UK mainland only)

Prestige Medical Ltd will, in the first twelve months from the date of purchase (or 18 months from the date of factory despatch – whichever is first), repair or replace free of charge any parts* inclusive of labour which prove to be defective in workmanship and / or materials.

Prestige Medical Ltd will not be liable in the event that the purchaser has failed to adhere to the instructions contained herein or if the autoclave has been abused, interfered with, altered, repaired or serviced by any unauthorised party. This may result in the protection provided by the equipment being impaired.

* This warranty **excludes** the door gasket, all internal furniture and consumables.

Consumer’s statutory rights are not affected.

The Prestige Medical Ltd policy is one of continuous development and as such reserves the right to change the specification of the models and items illustrated and described herein at any time.

Disposal

The WEEE directive places an obligation on all EU-based manufacturers and importers to take-back electronic products at the end of their useful life.

Prestige Medical Limited accepts its responsibility to finance the cost of treatment of redundant WEEE in accordance with the specific recycling requirements.

The symbol (shown below) is present on all Prestige Medical products, which indicates that the product must NOT be disposed of with other waste. Instead it is the user’s responsibility to dispose of their waste electrical and electronic equipment by handing it over to an approved reprocessor, or by returning it to Prestige Medical for reprocessing. For more information about where you can send your waste equipment for recycling, please contact your local city office or Prestige Medical.



Section 10: Printer instruction (Optional)

Power on procedure

Connect the printer to the power supply and switch on at the mains. The LED light will illuminate on the printer. Connect the printer to the autoclave with the cable supplied. The printer connection at the autoclave is connector ‘J’ (see page 4).

Replacing paper roll – **part no. 279505** (pack of 10)

If the printer roll needs replacing, open the paper cup lid and remove the remaining paper and bobbin. Reel off a few centimetres from a new roll, sit the new paper in the paper cup with the leading edge feeding from the bottom and close the lid. Press paper feed button to test.

Should the paper become creased or out of line when feeding in a new roll, cut the end off the paper roll, feed out the creased paper using the button, and reload ensuring the paper has a clean straight edge.

Status LED.

The printer incorporates an LED indicator to report its condition. If there is a fault the LED will flash in sequence. The fault can be identified by counting the number of flashes.

LED Indication.	Condition	Solution.
On	Printer On	-
Off	Printer Off or Asleep	-
* * *	Paper Out	Fit new paper
** ** **	Thermal head too hot	Allow head to cool

Place the printer on the worktop at the side of the autoclave.

Do not place the printer on the top of the autoclave.

Make sure the paper is kept away from hot surfaces such as the dump pipe etc.

Store the printouts in folders away from direct or indirect sunlight.

Data logger instructions

Refer to the instructions supplied with the data logger for setting up and operating the data logger.

Section 11: Specification

Chamber Capacities	16litre	22litre
Overall product width	480mm.	480mm.
Overall product height	410mm.	410mm.
Overall product length	440mm.	610mm.
Unpacked weight	42Kg. (Max)	43Kg. (Max)
Chamber Diameter	250mm.	250mm.
Chamber length	330mm.	430mm.
Max. Instrument length	290mm.	420mm.
Max. load non-vacuum	6 kg	6 kg
Max. load vacuum	6 kg (un-pouched)	6 kg (un-pouched)
*Pack size	2 kg (pouched)	2 kg (pouched)
110x110x50mm.	1 kg (porous)*	1 kg (porous)*
Sterilizing temp/time.	134°C/3½mins	134°C/3½mins.
	134°C/18mins.	134°C/18mins.
	121°C/15½mins	121°C/15½mins.
Operating pressure (Minimum)	2.05bar (gauge).	2.05bar.(gauge)
Voltage/Wattage	230v. /2200W	230v. /2200W
Frequency	50 – 60 Hz.	50 – 60 Hz.

NB. The overall cycle time will increase as the mains supply voltage decreases.

Chamber component materials.

Vessel:	Stainless Steel – 304 –S15
Boiler:	Aluminium – LM25
Door:	Aluminium – ASME SB26 356.0 T6
Door Plate:	Stainless Steel – 304 –S15

Fuses:

Mains plug top fuse (user replaceable)
F13A to BS1362 UK only.

Rating: All products are rated for intermittent use, continuously.

Heaters: Cast into the boiler.
Internal heater.

Temperature cut out:

Bi-metallic type rated at 180°C. with automatic reset.

Pressure release valve:

Operates at 2.9bar. Accumulation is <10%.

Maximum single fault temperature:

143°C determined by the pressure release valve.

Over voltage category: Group II

Pollution degree: Group II

Insulation: Class I.

Environmental conditions:

Indoor use at an altitude of up to 2,000m.
Ambient temperature range +10°C to +40°C
Maximum relative humidity 80% for temperatures up to 30°C, decreasing linearly to 50% at 40°C.
Mains supply voltage range 207 to 254volts.
Drying performance maybe affected by local environmental conditions.

Safety shutdown:

The machine is fitted with an automatic thermal reset mechanism. In the event of the boiler overheating (for example due to accidental overload), the unit will power down. After approx. 10 minutes, power will automatically be restored and the display will show Error O1. The load will need to be re-processed, ie start the cycle again.

Storage:

When leaving the unit standing idle for any length of time, switch mains off & drain the water tank especially if there is a possibility of the room temperature dropping below freezing point.

Packaging:

Packing materials used have been selected for ease of recycling. Please ensure you use the correct disposal system for disposal of packing materials.

Maximum water usage:

Vacuum cycles = 600mls per cycle (typical).
Non-Vacuum cycles = 450mls per cycle (typical).


Maximum power used:

16litre = 1.18kwh
22litre = 1.33kwh.

LEQ sound level = 60db.


Section 12: Cycle profiles

The profile below is for the  134°C /3½min vacuum cycle.



The profile for the  (18min) 134°C /18min. vacuum cycle differs only in the sterilizing hold time (stage 7 to 8).


The 134°C /3.5 min. steam penetration test  is identical to the above profile but without drying (Stage 9 to 10).

Programme Step	Time min:sec	Temperature (Measured Value)	Pressure (Measured Value)	Cycle identification.
START	00:00			
1	00:00 Typical		Point 1	
1 to 2	02:30 Typical		Point 2 300 mbar abs.	
2 to 3	06:30 Typical		Point 3 2.9 bar abs.	
3 to 4	06:00 Typical		Point 4 480 mbar abs.	
4 to 5	05:00 Typical		Point 5 2.90 bar abs.	
5 to 6	06:00 Typical		Point 6 480 mbar abs.	
6 to 7	07:00 Typical		Point 7 3.04 bar abs.	
7 to 8	03:30 Fixed	134 to 137°C.	3.04 bar abs. to 3.32 bar abs.	
8 to 9	01:30 Typical.			
9 to 10	15:00 Fixed.			
END	53:00 Typical			


The profile below is for the 134°C /3½min. cycle for Bagged solid instruments.






NB. Additional Drying must be added to this as detailed on page 7.



Programme Step	Time min:sec	Temperature (Measured Value)	Pressure (Measured Value)	Cycle Identification.
START	00:00		Point 1	
1 TO 2	02:00 Typical		Point 2 300 mbar abs.	
2 TO 3	09:00 Typical		Point 3 2.9bar abs.	
3 TO 4	01:30 Typical		Point 4 1.5bar abs.	
4 TO 5	02:00 Typical		Point 5 3.04bar abs.	
5 TO 6	03:30 Fixed.	134 to 137°C.	3.04 bar abs. to 3.32 bar abs.	
6 TO 7	02:00 Typical.			
7 TO 8	15:00 Fixed	ADDED DRYING – NOT SHOWN ABOVE. Could also be 05:00 or 10:00 depending on the amount selected.		
END	Typical. 35:00			

The profile below is for the cycles   (Non-vacuum cycle on a Vacuum Machine) the only difference being in sterilizing (Stage 3 to 4).



Programme Step	Time min:sec	Temperature (Measured Value)	Pressure (Measured Value)	Cycle Identification.
START	00:00			
1	00:30 & 00:30 Typical		Point 2 750-mbar abs. in both cases.	Figures in bold.
2 to 3	11:00 & 11:00 Typical		Point 2 3.04 bar abs. & 2.05 bar abs.	
3 to 4	03:30 & 15:30 Fixed	134-0 to 137-0°C. 121-0 to 124-0°C.	3-04 bar abs. to 3-32 bar abs. 2.05 bar abs. to 2.25 bar abs.	Figures in RED. 
4 to 5	02:30 & 03:30 Typical			
END	17:30 & 27:30 Typical			

On non-vacuum machines the vacuum assisted fill is not present.

THE CYCLE PROFILES SHOWN ON THIS AND EARLIER PAGES ARE FOR THE 16 LITRE AUTOCLAVE.

Section 13: Water quality

Must be suitable to produce steam in accordance with international standards.

Example specification for clean steam		
Determinant	Value	Recommended test for compliance
Based on sterilized water for Injections BP:		
Acid or Alkalinity.	NQ	BP test. Tests for pH are not an acceptable substitute.
Ammonium	0.2mg/litre	BP test or other suitable method
Oxidisable substances.	NQ	BP test.
Calcium and Magnesium.	NQ	BP test. Tests for hardness are not an acceptable substitute.
Heavy Metals.	0.1mg/litre	BP test. Tests for individual elements are not an acceptable substitute.
Chloride	0.5mg/litre	BP test or other suitable method.
Nitrate	0.2mg/litre	BP test or other suitable method.
Sulphate	NQ	BP test.
Residue on evaporation	30mg/litre	BP test. Conductivity measurement is not an acceptable substitute.
Pyrogens	0.25EU/ml	BP test.
Based on EN 285:		
Phosphate	0.1mg/litre	Any suitable method.
Silicate.	0.1mg/litre	Any suitable method.
Routine monitoring only:		
Electrical Conductivity at 25°C	35µS/cm	
NQ = Not Quantified; BP = British Pharmacopeia; EU = Endotoxin unit.		

USE OF WATER OUTSIDE THE ABOVE SPECIFICATION MAY INVALIDATE THE MACHINE WARRANTY.

Section 14: Loading the autoclave

Loading has a significant impact on how the autoclave performs.

The maximum permissible loads are as follows: -

- 6 kg for Non Vacuum Cycles
- 6 kg for Vacuum cycles (un-pouched)
- 2 kg for Vacuum cycles (pouched)
- 1 kg for Vacuum cycles (porous load)

Always use the instrument trays or racks, which are supplied.

Load instruments so that they do not touch other instruments or the chamber..

Only one item should be placed in a pouch.


Pouches may be placed on the Pouch Trays provided (additional trays may be purchased as an optional extra).

Pouches should be arranged so that they do not touch or overlap neighbouring pouches.

If using pouch trays, these should be spaced so that there is a good airflow between the trays.

When loading the trays into the rack use the top rungs of the rack first and work down.

Pouches should be placed on pouch trays with the paper side down as shown below.



NB The use of indicator tape for sealing pouches is not recommended in this autoclave.

